

# Portable Office for Refrigerated Warehouse

## Case Study

**Application:** Inplant Office in Refrigerated Warehouse

**Benefits Provided:**

- ✓ Reduced distance order picking personnel needed to travel to turn in paperwork
- ✓ Put supervisors closer to the action so they could help and monitor workers better
- ✓ Provided a warm environment in which employees could visit to take a break from the cold



### The Situation

A produce distributor in Maryland required supervisor offices for use in a refrigerated warehouse that was kept at 35°F year round. The client not only wanted to move its supervisors closer to its workers, but providing a warm office near them provided additional benefits.



### The Challenge

Since the client wanted the office built on a raised floor with the maximum amount of portability, we utilized one of our all-welded, pre-assembled buildings with forklift pockets. The building was outfitted with quick disconnects to the breaker box and forklift pockets so that it could be relocated quickly and easily. We also constructed it with additional insulation, insulated glass windows and a baseboard heater to keep it warm in the refrigerated warehouse.



### The Solution

The customer ended up ordering three portable offices, but after determining that they could meet their needs with only two units, they re-purposed the third unit to replace an outdoor guard booth. The story truly shows the versatility and flexibility of PortaFab's portable offices.